

## **Installation and Assembly Instructions for the 6 or 8B-Pressured Accessory Tank**

### **Assembly Parts Included:**

- |  |                               |
|--|-------------------------------|
| (1) Polyethylene 40 gallon tank with float | (1) 20" Length of 1&1/2" Hose |
| (1) Heavy-gauge steel mounting bracket     | (2) Hose Clamps               |
| (2) Hosebarb-PVC-1&1/2                     | (1) Elbow-1&1/2               |
| (1) Nipple-1&1/2xclose                     | (1) 3/4" Nipple & Hose swivel |

---

### **\*\*\* PUMP - INLET MUST BE INSTALLED FIRST. \*\*\***

**ELBOW- 1 & 1/2" must be installed on inlet of pump before wheels and axle for wheel kit assembly.**

### **Tank Frame to Pump Frame Hookup:**

Mount the tank with bracket on the pump frame, aligning the wide angle bracket feet with the pre-drilled frame holes. Secure with handle from wheel kit using 4 each of the 5/16 x 1 & 3/4" bolts, washers, and locknuts.

### **Tank Outlet to PUMP Inlet Hookup:**

1. Use pipe sealant on all fitting connections to ensure a tight seal.
2. Join the 20" hose with 1&1/2" Barb and tighten with a hose clamp over the connection.
3. Connect this assembly to the tank outlet, located on the bottom of the tank.
4. Take the nipple/elbow/hosebarb assembly and connect to pump inlet and angle towards the tank. Slide hose with clamp over barb and tighten.