



INSTALLATION INSTRUCTIONS

WK-STD WHEEL AND HANDLE KIT

*FOR WARRANTY REGISTRATION CALL: 1-800-245-4777
RICEHYDRO.COM*



RECOMMENDED TOOLS

1/2" WRENCH



1/2" SOCKET/RACHET



HAMMER



PARTS LIST

(2) 10" NO-FLAT TIRES



(1) HANDLE



(1) 5/8" AXLE



(2) 5/8" FLAT WASHERS



(2) 5/8" PUSH NUTS



(1) V-REST FOOT ASSEMBLY



(4) 5/16" X 18 LOCKNUTS



(8) 5/16" FLAT WASHERS



(2) 5/16" X 1" BOLTS



(2) 5/16" X 1 & 3/4" BOLTS



ASSEMBLY INSTRUCTIONS

Step 1. REMOVE 5/16" X 1 & 3/4" BOLTS, WASHERS, & LOCKNUTS

As shown below, remove from each side 5/16" X 1 & 3/4" BOLTS, WASHERS, & LOCKNUTS and save for STEP 4. Use Wrench/Ratchet to loosen bolts.



**UNDER ENGINE REMOVE BOLTS, WASHERS, & LOCKNUTS
FROM BOTH SIDES. SAVE TO USE FOR STEP 4**

Step 2. INSTALLING (1) 5/8" AXLE & (2) 10" NO-FLAT TIRES

Underneath the engine side, slide 5/8" AXLE through the existing hole where created in STEP 1, at the bottom of the base. Next, slide on 5/8" WASHER, slide 10" TIRE. Secure TIRE by hammering the PUSH NUT as shown below. Repeat for other side.



Step 3. INSTALLING (1) V-REST FOOT

Place V-REST FOOT under base using existing holes as shown below. Insert BOLT, 2 WASHERS, & 1 LOCKNUT in each existing holes. Use Wrench/Ratchet to tighten.



V-REST FOOT ASSEMBLY



Step 4. INSTALLING (1) HANDLE

Connect HANDLE on the inside of frame using existing holes as shown below. From STEP 1, use BOLTS, WASHERS, & LOCKNUTS with the rest from the package. Insert a BOLT, 2 WASHERS, & 1 LOCKNUT in each of the 4 existing holes on the top of the frame by the pump side. Use Wrench/Ratchet to tighten.



 +  + **FRAME** +  + 

HANDLE



x 4



x 8



x 4



5/16" X 1 & 3/4" BOLTS, WASHERS, & LOCKNUTS